
# Quick Start Guide

# **netvoyager**\*

# Neterm LX1000

- 1 Compact Flash Slot
- 2 USB\* 1
- 3 USB\* 2
- 4 Microphone In
- 5 Speaker Out
- 6 Power Switch
- 7 Flash Activity Status
- 8 Power Status
- 9 Mains Power On/Off
- 10 Com Port 1 (not in EU model)
- 11 Com Port 2 (not in EU model)
- 12 Wireless Antenna (not in EU model)
- 13 USB\* 3
- 14 Network Port 10/100-BaseT & connectivity LED
- 15 VGA Video Port
- 16 PS/2 Keyboard & Mouse (requires splitter)
- 17 Power Input



#### Installation Precautions

- Unpack your Netvoyager thin client carefully. All Netvoyager thin clients typically ship with an AC adapter and power cable unless the power supply unit was internal only a power cable is included.
- Carefully remove the contents of the container and keep the carton and the packing materials in case you need to send our device for service.
- Do not cover or block the ventilation of the case. Do not install near heat sources such as radiators or air ducts, or in a place subject to direct sunlight, excessive dust, mechanical vibration or shock. Do not place anything on the thin client.
- Allow sufficient space around the thin client for ventilation. Do not install the thin client in any enclosure with restricted air flow.

# **Power Connection Precautions**

- Do not connect the AC power to the thin client until all other peripherals are connected (including the power adapter).
- · Connecting and disconnecting equipment can cause power fluctuation which could cause damage to the thin client.
- Do not force connectors into sockets. If undue force is required, check connector orientation first before attempting connection.
- Use the supplied or the appropriate power cord for your local power supply to ensure regulatory compliance. Do not allow anything to rest on the power cord.
- Ensure that the power to the thin client is not interrupted whilst downloading or updating the software as this may cause software corruption.
- Disconnect the power plug from the power outlet under following conditions:
  - If you plan not use it for an indefinite period time.
  - When the power cord or plug is damaged of frayed.
- If the product has been dropped or the casing has been damaged.
- If the product exhibits a distinct change in performance, indicate a need for service.

## Maintenance Precautions

- · Clean the cabinet, glass, screen or controls with a soft cloth lightly moistened with a mild detergent solution. Do not use any type of abrasive pad, scouring powder or solvent, such as alcohol or benzene. Do not rub, touch, or tap the surface of the screen with sharp or abrasive items such as a pen or screwdriver. This type of contact may result in scratched glass, distorted plastic or damage to paint.
- Do not insert sharp objects or spill liquid into any of our products' ventilation holes. This may cause accidental fire, electric shock, damage or failure.
- Do not attempt to service this product yourself, as opening or removing covers or unauthorised modifications to the equipment will invalidate your warranty and may expose you to dangerous voltages or other risks.
- When you transport any of our devices or monitors for repair or relocation, use the original carton and packing materials.

### **Quick Start Steps**

- 1 Remove the thin client from its packing.
- 2 Place the thin client on the desk and use Netvoyager stipulated mounting accessory or approved mounting kits.
- 3 Connect all your peripherals to the thin client and the power cable.
- 4 Connect the power supply to the power source.
- 5 Switch on the device by using switch #9
- 6 Power on the device by using switch #6
- 7 Follow the boot sequence until the default settings are reached.
- 8 Configure your device according to the documentation and your needs
- 9 By using, or installing the product or software, or copying you agree to be bound by those terms.

## **Further Information**

WEEE & RoHS Compliance (EU Only) www.netvoyager.eu/general/environment.html

Netvoyager Products & Services End User License Agreement ("EULA") www.netvoyager.eu/general/legalsel.html

User Manuals

www.netvoyager.eu/support/documentation.html

<sup>\*</sup> not all USB devices are supported